


Secure Your Television



EarthquakeCountry.org/step1

Secure Your Television

Televisions can easily tip over or fall during earthquakes. Here are two options to prevent this.

Option 1: Attach the TV to furniture (as shown)

- Use flexible nylon strap packages, with buckle or Velcro fasteners, available at hardware stores and online.
- Stick one end of each strap onto the furniture as shown, following the package's instructions.
- Connect the other end to the back of the TV by screwing the strap into TV mount holes, or by sticking adhesive fasteners onto the TV.
- If the furniture the TV is on is tall, properly secure it to studs in the wall using a stud finder to find the correct locations.

Option 2: Attach the TV to a wall with a mounting kit (available where TVs are sold or online). Carefully follow the manufacturer's instructions.

